

3 Ways to Simplify Medical Device Testing

How can I setup and run these tests as quickly and easily as possible?

Our medical device testing setup answers this question with a three point approach: all *inclusive instrumentation*, *automation* and *ease of use*.



the tedious task of performing calibrations and validations on multiple pieces of equipment. Providing a built in source allows you to run the DUT for a line leakage test without taking up extra rack space with an external supply.





Automation

2.

Automating your test sequence with an all-inclusive instrument, combined with external multiplexors and software is the key to achieving both simple and efficient test sequences. We have seen this setup save as much as 11 minutes off medical device production line tests.

All tests one sequence



OMNIA[®] II + SC6540+ Autoware[®]



As part of our MedTEST system, we offer high voltage multiplexor. Having your OMNIA II connected to these multiplexors mitigates operator error by automatically switching connection points for each individual test. While the entire test sequence can be set manually through the front panel of the OMNIA II, utilizing software to remotely set and save test sequences is a more efficient method of creating the test sequence.





Ease of Use

3.

Autoware III is our out of the box software solution. It provides a graphical user interface for setting up and navigating test settings. It has a drag and drop interface that easily allows for customization of test routines. It can be used to set all test parameters, save the sequence for later use and record all test results.



The program also has the capability to associate a product's model and serial number with a particular test sequence. When the model and/or serial number is entered by the operator, the proper test sequence automatically loads. Also, text, audio and video instruction prompts can be added to each step of the test sequence. This allows detailed instructions to be added to each test. This negates user error in running an incorrect test sequence.

Data Path	ments and Setting	\Soliton\Deskto	p\data.txt	1	listory All	Last	Clear								
Filters											1	Instrument	Address	Image	Status
Option	Sub-Option	From	Тө		Option	Sub-Option	From	Тө		Γ.		Omnia 8106	1	·	
			1			2		1				Ummia 8106	•	•• • 28 ¥	OK
		12	12			12	12	1	63	2		Sample	Demo		OK
			12			1		1							
						_				3		6201.	19	·•••••••••••••••••••••••••••••••••••••	OK
	1	1	1				1							1999 - 1997 - 1997 - 1997 - 1997 - 1997 - 1997 - 1997 - 1997 - 1997 - 1997 - 1997 - 1997 - 1997 - 1997 - 1997 -	
Itered Result	5											310KAC	Demo	1 11100	OK
Result No.	Step		Pass/Fail	Test Result	Meter 1	Meter 2	Meter 3	Meter 4	Meter 5						
105	1		Pass Pass	Pass Pass	1.24 kV 1.24 kV	An 000.0 An 000.0	Am 000.0								
107			Pass Pass	Pass	1.24 ky	0.000 mA	0.000 mA								
108	2		Pass	Pass	0.22 ky	0.0 uA	0.000 ma								
109			Fal	Hound	0.00 A	>600 mOhms									
110			Fal	HE-Link	0.00 A	>600 mOhms									
111			Fal	Hound	0.00 A	>600 mOhms									
112	1	Insulation Resistance		Pass	500 Y	>50000 MOhms									
113	4		Fal	HC-Link	0.00 A	>600 mOhms					_				
114			Fal	HE-Limit	0.00 A	>600 mOhms					2	100000	(D)		Delete Instrument
115			Fal	HELINK	0.00 A	>600 mOhms				6	J R	escan	Add In	scrument	Delete instrument
116	3	Insulation Resistanc		Pass	500 V	>50000 Mohms				1.5					
117			Fal	HOUNE	0.00 A	>600 mOhms				<u> </u>	_				/
118			Fel	Hilling	0.00 A	>400 m hms									
<									>						

Visit us online to learn how MedTEST can simplify your testing

